Heating water treatment in mini format

The new mixed bed cartridge desaliQ:MB5 for initial filling, make-up water feed and rehabilitation





Saving energy and money thanks to treated heating water. We will be pleased to advise you.



Your benefits at a glance



Versatile and flexible

Whether initial filling, make-up water feed or rehabilitation – the mixed bed cartridge desaliQ:MB5 can be used variably for full demineralisation or filtration.



Compatible

Make use of tried and tested Grünbeck accessories: desaliQ resin bag or desaliQ inline filter module. Both products can also be used with mixed bed cartridge desaliQ:MB9.



Convenient for installer and customer

Thanks to the heat resistance of the cartridge and the accessories, heating water can be treated during ongoing heating operation. Thus, the equipment can be applied all year round.



Immediately ready for use

The mixed bed cartridge desaliQ:MB5 comes filled with one resin bag.



Small and lightweight

With its low weight and a height of only 35 cm, the desaliQ:MB5 is easy to transport and can easily be stowed in any car.

Technical specifications

| Mixed bed cartridge desaliQ: | MB5 |
|------------------------------|--------------|
| Nominal connection diameter | 3/4" |
| Resin bag of 6 litres | 1 |
| Capacity < 10 [µS/cm x m³] | 135 |
| Capacity < 50 [µS/cm x m³] | 242 |
| Nominal flow [m³/h] | 0.5 |
| Weight incl. resin bag [kg] | approx. 10 |
| Max. water temperature [°C] | 65 |
| Order no. | 707000060000 |



Accessories



desaliQ resin bag

- Amount of resin portioned for exactly one filling of the desaliQ:MB5
- Quick and easy replacement of the resin
- Intelligent distribution system within the mixed bed cartridge for a uniform flow through the bag from bottom to top
- Order no. 707 435 (2 bags of 6 litres each)

desaliQ inline filter module

- 6 Filter elements guarantee efficient filtration
- Pore size of 5 µm to reliably retain impurities
- Integrated high-performance magnet to remove metallic and magnetic particles
- Quick and easy cleaning of the high-performance magnet
- Order number of desaliQ inline filter module 707000010000
- Order number of desaliQ inline replacement filter elements 707000020000

